



Thermal Roof Liner Fitting Instructions

2CV

The liner has no fixings. It tucks in between the canvas roof and the cross struts. At the front it tucks between the roof and the clamp-bar and at the back it tucks between the roof and the cross member above the rear window. Stretch it out to avoid sagging.

Dyane

Remove the 3 small screws inside the tailgate hinge cross member and replace them with the 3 threaded press-studs supplied with the roof liner.

Press the studs on the back edge of the liner onto the 3 studs.

With the roof open and laying down the back of the car, thread the liner between the roof fabric and the 4 bars which are riveted to the roof.

The front edge of the liner tucks between the roof and the clamp-bar.

Pull it forward as tightly as possible.

13 Lewis Road, Chichester, West Sussex PO19 7LZ

Tel: 01243 780132 Fax: 01243 790009

Email: info@matts-soft-tops.co.uk Website: www.matts-soft-tops.co.uk